


ChefsTemp^o

CHEFSTEPM 4-IN-1 PROBE CHARGER

USER MANUAL



Fast
Charging



Charges Up
to Four Probes



Type-C Cable
Compatible



Compact and
Space-Saving

QUICK PROBE CHARGING FOR PERFECT COOKING


ChefsTemp 4-in-1 Probe Charger

Overview:


The ChefsTemp 4-in-1 Probe Charger is designed to keep your ChefsTemp wireless probes charged and ready for use. Simply connect it to a 5V2A power adapter and a Type-C charging cable (adapter and cable are not included) for effortless charging. The ChefsTemp 4-in-1 Probe Charger can accommodate up to four probes simultaneously, compact and convenient, ensuring you're always prepared for your next grilling or cooking session.

Operation:

Charging the Charger: Connect the Type-C adapter as shown below. The green indicator light beside the Type-C port will light up upon successful connection.




Charging the Probe: Place the probe as shown below.



When the probe is charging, the red indicator light above the probe will light up. Generally, a probe without power will be fully charged after 10-15 minutes. When the probe is fully charged, the red indicator light will turn green (automatically turn off after 5 minutes).

If there is a short circuit in the charging case, charging will immediately stop, and the red indicator lights will flash. Please reinsert the probe to resume charging.

800mAh Built-in Rechargeable Battery – Up to 20 days runtime with normal use (charge every 20 days).



What's included:

1* ProTemp 4-in-1 Probe Charger

1* User Manual

Support:

If you have any issues with your device, please feel free to contact us:

Tel: +1(559)563-8838

E-mail: info@chefstemp.com

Website: www.chefstemp.com

ChefsTemp^o